



Extension Plate

INSTALLATION INSTRUCTIONS

Item No.: 213065
Vertical Extension Plate

Extension Plate with pre-drilled holes for the ProClip and AMPS standard.

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Extension Plate.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The Extension Plate in the installation pictures may look different from the one you have received. However, the same instructions apply.

Overview Picture



1.

Press a screwdriver (Phillips) firmly through the predrilled holes in the Extension Plate to open them up. (If they are closed)
(As long as you are using the screws you don't have to peel off the cover of the adhesive tape)
Place the Extension Plate in your hand so the three center lined holes are towards the top and then place the Extension Plate onto the ProClip so the holes match, then screw the Plate to the ProClip using the enclosed screws.



2.

When properly attached, you can attach holders etc. to the extension plate i.e. a cell phone holder as shown in the picture.
Place the cell phone holder onto the Vertical Extension Plate so the holes match, then screw the holder to the Extension Plate using the enclosed screws.



3.

The Extension Plate is now in place as shown here (with a Nokia Phone attached to it) and in the overview picture above.

