

INSTALLATION INSTRUCTIONS

Move Clip



Male Plate in direct use on the device
Switch between two devices using one
dashboard mount etc.

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Move Clip Plate.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look different from the one you have received. However, the same instructions apply.

Overview Picture



1.
Place the Female Plate directly onto the ProClip or to the Tilt Swivel attached to The ProClip, so the holes match, and then screw the Plate to the ProClip/Tilt Swivel using the enclosed screws.



2.
Clean the back of your device with the enclosed alcohol pad and peel off the cover of the adhesive tape on the male Plates. Attach the Plates onto the back of your devices or to the backs or bases of your holder.
Press the Plate firmly towards the device for best possible attachment of the adhesive tape.
Note; if the device is left hanging in the car in extreme heat for hours (i.e. on a parking lot for a hole day), it may slide off. ProClip USA may not be held liable for any damage to the device and/or vehicle in the event that this should occur.



3.
Slide the device down into the V-groove in the Female Plate

The Move Clip is now in place as shown in the overview picture above.

