



Item No.: 215181

6 Inch Goose Neck Mount
with AMPS Hole Pattern

Installation Instruction

Overview Picture

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



Note: DO NOT attach anything to this mount until after you have attached the mount to the dashboard. If you do, you will make it more difficult to attach the mount, and by screwing into it, it is then considered used and therefore non-refundable. See terms on back.

1. Place the end of the mount with the large pre-drilled holes toward the applicable surface and attach it with appropriate screws (not included).
2. Attach the applicable Holder to the face plate with the small pre-drilled holes. If you have a device/holder/cradle with a different hole pattern you can always drill wider holes or new holes to match your device, or simply use self tapping screws and screw directly into the faceplate.