



**Item No.: 215198
2 Prong (Dual T)
Vehicle Mount Adapter**

Works with all devices/device cradles that have female Dual T holes in the back.

Installation Instruction

Overview Picture

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Adapter Plate.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip Adapter in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



Note: The 2 Prong (Dual T) Vehicle Mount Adapter can be attached to any mounting bracket or flat surface with the applicable screws enclosed - self-tapping screws if the mount has small holes or machine screws with nuts if the mount has large holes.

1.
Place the 2 Prong (Dual T) Vehicle Mount Adapter over the matching holes in the dash mount.



2.
Attach it with the enclosed screws – self-tapping screws if the mount has small holes or machine screws with nuts if the mount has large holes.



3.
The 2 Prong (Dual T) Vehicle Mount Adapter is now in place.





**Item No.: 215198
2 Prong (Dual T)
Vehicle Mount Adapter**

Works with all devices/device cradles that have female Dual T holes in the back.

Installation Instruction

Overview Picture

4.
Now that the Adapter Plate is in place, find your device cradle, which is usually enclosed with your device when purchased. (HP Enhanced Car Cradle shown in picture) If you don't have a cradle, please go to step 6.



5.
Align the female Dual T holes on the back of the device cradle with the Dual T Vehicle Mount Adapter.



6.
Hook your device/device cradle onto the T prongs and slide it down.

To remove it, slide the device up and unhook it from the T prongs.



7.
The device cradle is now in place.

