



Item No.: 803606  
Left Mount



Volkswagen Passat, 06-Current

## Installation Instruction

## Overview Picture

**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**ProClip USA** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

**ProClip USA** may not be held liable for any personal injury resulting from accident or improper use or installation.

**The ProClip** mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



**Note:** The adhesive tape referred to below does not leave any marks or damage the dashboard, and it is easy to remove.

1. Press the thin end of the enclosed gap openers into the gap between the dashboard and the air vent, to widen the gap.
2. Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in ProClip is at the top. Press/hook the angled edge on the lower part of the ProClip under the air vent overhang.
3. Press down on the top right side of the ProClip so the angled edge goes into the gap between the gap openers.
4. Press down on the top left side of the ProClip so the rest of the angled edge goes into the gap between the gap openers. Pull out the gap openers.

The ProClip is now in place as shown in the overview picture above.

