



Dashboard Mount

INSTALLATION INSTRUCTIONS

Item No.: 832860
Console Mount

Volkswagen Passat, 97-Current

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The **ProClip** mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

Overview Picture



1. Peel off both adhesive tape covers on the ProClip. Hook the long lower part of the ProClip under the edge of the console.



2. Pull the ProClip upwards. Hook the upper part of the ProClip over the edge of the console.

The ProClip is in place as shown in the overview picture above.

