



Item No.: 833604
Console Mount, Angled

Volkswagen Passat, 06-Current

Installation Instruction

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

Overview Picture



Note: The adhesive tape referred to below does not leave any marks or damage the dashboard, and it is easy to remove.

1.
Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top.
Press the angled edge on the left side of the ProClip into the gap between the center console panel and the console edge.



2.
Press firmly down on the right side of the ProClip so the angled edge hooks over the console edge by the floor.
Press until you see or hear/feel it snaps into place.



3.
Press on the lower part of the ProClip to make sure the angled edge is correctly attached.



The ProClip is now in place as shown in the overview picture above.