



## Dashboard Mount

## INSTALLATION INSTRUCTIONS

Item No.: 852428  
Angled Mount

Porsche 911 series, 99-04  
Porsche Boxster, 97-04

**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**ProClip USA** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

**ProClip USA** may not be held liable for any personal injury resulting from accident or improper use or installation.

**The ProClip** mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

### Overview Picture



1.  
Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top.  
Place the angled edge on the left side of the ProClip into the gap between the center console panels and the console edge.



2.  
Press firmly forward on the right side of the ProClip so the curved edge on the right side of the ProClip hooks behind the console edge by the carpet.



3.  
Make sure the curved edge on the ProClip has hooked properly behind the console edge by pressing it towards the console wall/edge.

The ProClip is now in place as shown in the overview picture above.

