



Dashboard Mount

INSTALLATION INSTRUCTIONS

Item No.: 852871
Angled Mount

Audi A4/S4 Avant, 2003-2008 (US)
Audi A4/S4 Sedan, 2002-2008 (US)
Audi A4/S4 Avant, 2002-2007 (EU)
Audi A4/S4 Sedan, 2001-2007 (EU)

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

Overview Picture



1. Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top. Place the ProClip over the center dash console edge. Note: avoid making the adhesive tape attach yet – it will automatically attach during the rest of the installation procedure.



2. Press the left side of the ProClip towards the padded console edge and at the same time, press forward on the ProClip so the grooved edge goes into the gap between the console edge and the stereo. Press until you see or hear/feel it snaps into place.



3. Press forward on the right side of the ProClip so the angled edge goes into the gap between the center console edge and the center console sidewall. Press until you see or hear/feel it snaps into place.



The ProClip is now in place as shown in the overview picture above.