



Dashboard Mount

INSTALLATION INSTRUCTIONS

Item No.: 852903
Center Mount



Honda Civic, 01-Current
Honda Civic Hybrid, 03-Current
Acura EL, 01-Current

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

Overview Picture



1.

Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top. Press the thin end of the enclosed gap opener into the gap between the padded dashboard and the air vent panel frame to widen the gap. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Adjust the ProClip so the vertical part on the lower part of the ProClip is positioned over the gap between the climate control and the padded dashboard edge. Pull out the gap opener.



2.

Press the thin end of the gap opener into the gap between the climate control and the padded dashboard edge, below the ProClip, to widen the gap.



3.

Press firmly forward on the lower part of the ProClip so the grooved edge goes into the gap. Press until you see or hear/feel it snaps into place.

The ProClip is now in place as shown in the overview picture above.

