



Dashboard Mount

INSTALLATION INSTRUCTIONS

Item No.: 853256
Center Mount



Ford Explorer, 02-Current
Mercury Mountaineer, 02-Current

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

Overview Picture



Note: The ProClip can be attached on either side of the air vent as shown in the overview picture. The instructions below apply for both placements.

1.

Press the thick end of the enclosed gap opener into the gap between the center console panel frame and the air vent panel frame, to widen the gap.



2.

Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.



3.

Press upwards and forward on the lower part of the ProClip so the grooved edge hooks over the air vent edge.



4.

Press down on the inner side of the ProClip to make sure the grooved edge snapped properly into place. Adjust the air vent.



The ProClip is now in place as shown in the overview picture above.