



Item No.: 853359

### Angled Mount

Volkswagen Jetta, 2005.5-Current  
Volkswagen Jetta SportWagen, 2009-Current  
Volkswagen Golf, 04-Current (EU)  
Volkswagen Golf, 07-Current (US)  
Volkswagen Golf Variant, 07-Current (US)  
Volkswagen GTI, 07-Current (US)  
Volkswagen Rabbit, 07-Current (US)

**Note:** This mount fits with all the optional stereos for these car models such as the ones shown below.

## Installation Instruction

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

## Overview Picture



**Note:** DO NOT attach anything to this mount until after you have attached the mount to the dashboard. If you do, you will make it more difficult to attach the mount, and by screwing into it, it is then considered used and therefore non-refundable. See terms on back. The adhesive tape referred to below does not leave any marks or damage the dashboard, and it is easy to remove.

1.

Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in ProClip is at the top. Press the angled edge on the right side of the ProClip into the gap in the sidewall (see arrow in picture)



2.

Place your hand on the right side of the ProClip and push it towards the stereo so the angled edge on the left side goes into the gap between the stereo and the center console panel frame. Press until you see or hear/feel it snaps into place. **NOTE: the angled edge goes into the gap by the stereo. See arrow in picture.**



3.

Place your fingers against the left part of the ProClip and push forward to make sure the angled edge is all the way into the gap.



The ProClip is now in place as shown in the overview picture above.