



Item No.: 853480
Angled Mount



Audi A6, 05-Current

Installation Instruction

Overview Picture

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



Note: The adhesive tape referred to below does not leave any marks or damage the dashboard, and it is easy to remove.

1.
Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded part of the dashboard, to widen the gap.



2.
Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top.

Place the grooved edge on the ProClip towards the gap and press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap.



3.
Press firmly forward on the lower part of the ProClip so the grooved edge goes into the gap. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

The ProClip is now in place as shown in the overview picture above.

