




Item No.: 853603
Center Mount



Volkswagen Passat, 06-Current

Installation Instruction

Overview Picture

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



Note: The adhesive tape referred to below does not leave any marks or damage the dashboard, and it is easy to remove.

1.
Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the padded dashboard, to widen the gap.



2.
Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top.
Place the angled edge on the lower part of the ProClip underneath the dashboard overhang.



3.
Press firmly down on top of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place.
Pull out the gap opener.



The ProClip is now in place as shown in the overview picture above.