



Item No.: 853643  
Angled Mount



Chevrolet Corvette, 2005-2007

## Installation Instruction

## Overview Picture

**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**ProClip USA** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this dashboard mount.

**ProClip USA** may not be held liable for any personal injury resulting from accident or improper use or installation.

**The ProClip** mount in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



**Note:** The adhesive tape referred to below does not leave any marks or damage the dashboard, and it is easy to remove.

1.  
Peel off the cover of adhesive tape on the ProClip. Place it in your hand so the ProClip label (sticker) is in an upright position, or if vertically positioned; the P in the beginning of ProClip is at the top. Press the angled edge on the right side of the ProClip into the gap between the console sidewall and the padded part of the dashboard.



2.  
Continue to press forward so the angled edge on the left side goes into the gap between the console edge and the center console panel frame. Then continue to press forward on the right side of the face plate until you hear/feel the right angled edge snaps into place between the console sidewall and the padded part of the dashboard.



3.  
Press firmly forward on the left side of the ProClip for best possible attachment of the adhesive tape.

The ProClip is now in place as shown in the overview picture above.

