



Standard Holder

This instruction sheet applies for all types of the Standard Holders, even if the design of your Holder is different from the pictures shown below. The hook on the side of the Holder is for your headset or cigarette lighter cable when not in use.

Installation Instruction

Please read all of the instructions and look at the pictures before attaching the Holder.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Holder.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip Holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

Overview Picture



Note: The holder can be attached to any mounting bracket or flat surface with the enclosed screws. The installation pictures show an installation onto an easily self-install ProClip Dashboard Mount. With this mount you use the self-tapping screws. With most other mounting brackets you will have to use the machine screws with nuts.

1.

Place the lower hole in the Holder over the hole on the lower part of the ProClip Dashboard Mount. Screw one of the enclosed self-tapping screws through the hole in the Holder and into the hole on the lower part of the ProClip Dashboard Mount. (Note: If the holes in the holder are not fully open, press a screwdriver (Phillips) firmly through the predrilled holes in the Holder to open them up.)



2.

Screw one of the enclosed self-tapping screws through the hole in the upper part of the ProClip Dashboard Mount.



3.

The Holder is now in place as shown here and in the overview picture above. You can now slide your phone/handheld down into the holder.



Note: The hook on the side of the Holder in the picture only comes on Mobile Phone Holders and is used for hanging a headset or cigarette lighter cable when not in use.