



Item No. 215052
V-Slot Button & Clip Holder

The V-Slot Button & Clip Holder will accommodate devices, cases, or holsters that have buttons or belt clips of various sizes.

Installation Instruction

Overview Picture

Please read all of the instructions and look at the pictures before attaching the ProClip.

ProClip USA may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Holder.

ProClip USA may not be held liable for any personal injury resulting from accident or improper use or installation.

The ProClip Holder in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.



Note: The holder can be attached to any mounting bracket or flat surface. The enclosed screws are self-tapping screws. The installation pictures show an installation onto a ProClip Vehicle Mount. If you are going to attach the Holder to a metal bracket you may have to use machine screws and nuts. (Not included)

1.
Place the V-Slot Button & Clip Holder over the matching holes in the ProClip Vehicle Mount and attach it with the enclosed screws.

2.
If the V-Slot Button & Clip Holder has large holes as shown in the picture you would need machine screws and nuts (not included) or you can do as described below in #3.

3.
Place the V-Slot Button & Clip Holder slightly above or below the large holes in the ProClip Vehicle Mount and attach it with the enclosed self-tapping screws. Press the screw firmly towards the mount while screwing and after a few turns the screw will start to grip and go through the Mount.

4.
The Holder is now in place as shown in the overview picture above.

Slide your device down into the Holder.

