



## Item No. 215395 Left/Right Extension Plate

This Extension Plate has pre-drilled holes for the ProClip and AMPS standard.

The purpose of this plate is to extend your device from the center console so it doesn't cover any buttons, control wheel, CD slots etc.

### Installation Instruction

**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**ProClip USA** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Extension Plate.

**ProClip USA** may not be held liable for any personal injury resulting from accident or improper use or installation.

**The ProClip** Ext. Plate in the installation pictures may look slightly different from the one you have received. However, the same instructions apply.

### Overview Pictures



**Note:** The Extension Plate can be attached to any mounting bracket or flat surface with the applicable screws enclosed - self-tapping screws if the mount has small holes or machine screws with nuts if the mount has large holes.

1.

Press a screwdriver (Philips) firmly through the pre-drilled holes in the Extension Plate to open them up. Place the Extension Plate over the matching holes in your mounting bracket. Attach it by using the applicable screws enclosed – self-tapping screws if the mount has small holes or machine screws with nuts if the mount has large holes.



2.

Attached the base plate from the Holders tilt swivel to the Extension Plate with the enclosed screws in the Holder packaging.



3.

Attach your Holder onto the Extension Plate. (see separate instruction enclosed with the Holder)  
The Device shown in the overview picture above is a TomTom XL navigation unit.

